

WAX RECOMMENDATION

EVENT

Boyne Highlands Classic - Saturday, March 8th
Boyne Highlands Resort, Harbor Springs, Michigan

Forecast: Friday night low around 0 F, Saturday morning temps rising to 15 F.

Base Prep: Clean skis with SWIX CH10, BP88 or BP99 - scrape and brush using SWIX Course Bronze Brush(T0158) or SWIX Fine Steel Brush (T0192). Apply a layer of NEW SWIX MB77 Molly Base Prep. Scrape and brush. Clean kick zone with Swix base cleaner and Fiberlene, sand kick zone with 100grit sandpaper

Structure: Fine linear, Can be applied with the Swix Super Riller using the .25mm blade

GLIDE WAX - FAST

Base Race Wax: Apply CH6, scrape and brush using Medium Bronze Brush
* Repeat above for even faster skis! Polish with SWIX Blue Nylon Brush (T160) after warm-up

GLIDE WAX - FASTER

Race Wax: Apply LF4, scrape and brush using Medium Bronze Brush
* Repeat above for even faster skis! Polish with SWIX Blue Nylon Brush (T160) after warm-up

GLIDE WAX - WICKED FAST

Base Race Wax: Apply LF4, scrape and brush using Medium Bronze Brush Race Wax: Apply FC7 Powder. FC7 is ironed twice during application. Ironed, brushed back to powder form, and ironed again. Brush up using SWIX Stiff Black Nylon Brush (T0194) or NEW SWIX Wild Boar (T0164) after 1st ironing. After 2nd ironing, brush out with using SWIX Stiff Black Nylon Brush (T0194) or NEW SWIX Wild Boar (T0164). Final brush with SWIX Blue Nylon Brush (T0160).

KICK WAX

Base Kick Wax: Apply a thin layer of VG35 Base Wax (iron in or use heat gun) & cork smooth. This layer will add durability and act as a cushion.

Race Wax: Apply several layers of VR30 or V20 Blue Extra - cork in each layer. Cover with short layer of VR40 or V30 if extra grip needed & cork smooth.

* FC1 Solid could be hand-corked in and brushed out with Fine Nylon Brush

For detailed application instructions check out the NEW Swix Racing Website: WWW.SWIXRACING.US

